



## ONLY 4 SIMPLE STEPS TO INSTALL!



### DRILL HOLE & LEVEL UP

The diameter of the hole should be adjusted to the thickness of the installed pole about 1-2 inches bigger than the diameter of the post. Hold the pole in the correct position firmly enough so that it doesn't move in the QUIKSET growing and curing proces. **No standing water in the hole before installation.** Put safety gloves on. Be sure to clean off access debris around the post.



### REMOVE CLIP & MIX

Remove clip with one quick motion by pulling the ends of the bag aside. Mix the two components by pulling the bag back and forth against a blunt edge. **WARNING!** DO not mix for longer than 30 seconds, as this may result in the bag bursting and contents being released uncontrollably at a high pressure. this can be harmful.



### TEAR UP & POUR

Tear off where indicated. Pour all of the contents into the hole carefully on each side of the pole. Wait for the next 3-5 minutes keeping the pole as stil as QUIKSET expands. After another 1-2 minutes the pole stabilizing elements can be removed. QUIKSET should grow at least 4-5 inches below ground level.



### CUT CLEAN & COVER

Cut clean if grows over ground level, after only 15-30 minutes QUIKSET will be hard enough to cut the exces off with a shovel or a knife. Cover with soil to protect it from direct sun. Full strength after 90 minutes!

FOR MORE INFORMATION  
CONTACT US:

5404 Hoover Blvd. Suite # 14  
Tampa, FL 33634  
Office: (813) 280-2419  
Fax: (813) 513-2565

[info@15minuteconcrete.com](mailto:info@15minuteconcrete.com)  
[www.15minuteconcrete.com](http://www.15minuteconcrete.com)